



714-772-5202 FAX 714-772-2302

web: www.majormfg.com

**INSTRUCTIONS FOR USE WITH
HIT-40SL3 INSTALLATION TOOL
FOR SCHLAGE KC9000 SERIES KING COBRA**

1. Remove the outside cylinder and install the supplied HIT-22 guide.
2. Place the drill rod in center hole of guide.
3. Place the HIT-40SL3 drill guide over the drill rod. There should be one drill bushing above the rod and two below.
4. Square the guide to door and drill the top hole with a 5/32" drill bit.
5. Insert a second 5/32" bit into the top bushing and into the hole drilled in the door, this will keep the drill guide aligned.
6. Drill the two bottom holes.
7. Remove the HIT-40SL3 from the door and the HIT-22 from the lock.
8. Tap all three holes 10-32 and install the Schlage Cobra lock per factory instructions.

***ALWAYS WEAR SAFETY
GLASSES WHEN USING
POWER TOOLS!!!***