

LOCK CYLINDER INSTALLATION FOR KT-500 SERIES KEY TRAP USING SCHLAGE INTERCHANGEABLE CORE CYLINDERS.

Thread Schlage Interchangeable core cylinders into the key trap as shown in the picture. Due to the length of the cylinders use the provided cylinder spacers.



Secure cylinders with two set screws. The cylinders should be screwed down on the spacer rings on the top of the key trap.



With the cylinders secured with the cylinder set screws, remove the cams from the back of the cylinders. **It is a good idea to do this step with the interchangeable cores installed in the cylinder housing.**



Major
MANUFACTURING, INC.

1825 Via Burton, Anaheim, CA, 92806

714-772-5202 / Fax 714-772-2302 / Email / mail@majormfg.com / web www.majormfg.com

The timing link used is shown at the right. Install one side to one of the mortise cylinders. Put a key into the opposite cylinder and turn until you can line up the cam on the cylinder and secure with a cam screw. The key trap is now ready to use.



Completed installation of the Schlage Interchangeable core cylinders. Link will allow only one key to be removed at a time. Returning one key will allow removal of the other.

Major
MANUFACTURING, INC.

1825 Via Burton, Anaheim, CA, 92806

714-772-5202 / Fax 714-772-2302 / Email / mail@majormfg.com / web www.majormfg.com