

# **DIRECTIONS TO TIME BEST TYPE CYLINDERS IN KT-300 SERIES KEY TRAPS**

## **KT-310 / KT-320 / KT-330 / KT-340**

1. With a control key install a keyed core in one of the two housings in the key trap.
2. Insert the operating key and rotate 180 degrees.
3. With the control key, install the second cylinder and remove control key.
4. The first operating key is now locked in the key trap unless a second key is put in the opposite cylinder and rotated 180 degrees. By doing this it will become locked and allow the first key to be removed.



**Major**  
MANUFACTURING, INC.

1825 Via Burton, Anaheim, CA, 92806

714-772-5202 / Fax 714-772-2302 / Email / [mail@majormfg.com](mailto:mail@majormfg.com) / web [www.majormfg.com](http://www.majormfg.com)