



1825 VIA BURTON
ANAHEIM CA 92806
714-772-5202 / FAX 714-772-2302
EMAIL: MAIL@MAJORMFG.COM
WEB: WWW.MAJORMFG.COM


**INSTRUCTIONS
FOR
HIT-66-250 TEMPLATE
FOR
KABA E-PLEX 5000
SERIES MORTISE LOCK
WHEN USING POWER TOOLS
ALWAYS WEAR
EYE AND EAR PROTECTION!!**

THINK SAFETY!!


**WHEN USING POWER TOOLS
ALWAYS WEAR
EYE PROTECTION!!**

Before attempting any installation know how to safely use the power tools involved. Be sure all bits and cutters are sharp and in good condition and all power tools and extension cords are in good working order and properly grounded. **AND MOST IMPORTANTLY, BE SURE TO WEAR, EYE AND EAR PROTECTION.**

Copyright 2010—Major Manufacturing



With both clamps opened equally, install both inside and outside templates to the HIT-66 clamp as shown. Do not tighten the 10-32 screws at this time. When all screws have been loosely installed, then it is ok to tighten.



Install the alignment guide to either side of the template set. This is used to align the template with the mortise pocket.




Shown is a standard mortise pocket, we will use this as a basis for the Kaba 8100 series install.



Install the mortise lock positioning plate. The plate will fit into the 1-1/4" x 8" faceplate cut out. There will be a 3/8" diameter pin centered on the plate. There is no top or bottom to worry about.



Slide the HIT-66 alignment fixture over the alignment pin and tighten to door. Alternate tightening between the top and bottom clamp. Do not attempt to tighten one clamp all the way at once.



There are two drill guides that fit the in the bottom of the drill guide. One for the 1/4" thru bolts and one for the 2-1/8" spindle hole.




Using the supplied 10-32 x 3/4" flat head screws, install the 1/4" diameter drill guide first. It is easier to drill the smaller hole first as they are located at the very edge of the 2-1/8" hole.



Drill 1/4" holes on both sides of the door. They will go to the mortise pocket. Do not try to drill all the way through both sides at once.




With the 1/4" bit still in the drill, drill the top holes. Again drill half way from both sides of the door.






Remove the 1/4" drill guide from both sides of the guide and replace with the 2-1/8" hardened guide.



Using a hole saw, drill these holes, use a slow speed on the drill.



The last hole needed is for the t-turn spindle. Use a 1/2" diameter drill bit and drill both sides of the door.





Completed installation

That's all there is to it!

Visit our web site at www.majormfg.com for more information on lock templates and a complete listing of all the tools we have available. While there, sign up for our newsletter and we will email new product